



HORTUS[®]
outdoor wood flooring

300 x 300 Tile

(finished product with grid base): 300 x 300 x 32 mm

1

CHEKERBOARD pattern

Hortus Tile
300 x 300
CHEKERBOARD pattern

Surface covered:
0,81 m² approx.



INSTALLATION

(checkerboard pattern)



1 Place the first tile in a corner of the area to be covered, laying it with the strips in a vertical direction.



2 Click the female joints of the first tile onto the male joints of the second tile, which will be placed with the strips in a horizontal direction.



3 Install all the tiles alternating horizontal and vertical strip direction.



4 When clicking into place the second tile of the second row, lift all the tiles already laid because in this corner you will have two male joints.



5 To click in the new tile, you need to ensure that the female joints are inserted under the male joints of the laid tiles.



6 When clicking into place the third tile of the second row, lift the previous tile in the same row, so you click the male joints into the female joints of the new tile.



7 For the tile side that clicks onto the first row, simply click the male joints into the female joints of the corresponding tile.



8 Example shows correctly installed floor.



HORTUS[®]
outdoor wood flooring

300 x 300 Tile

(finished product with grid base): 300 x 300 x 32 mm

2

LINEAR
pattern

Hortus Tile
300 x 300
LINEAR pattern

Surface covered:
0,81 m² approx.



INSTALLATION

(linear pattern)

1



Place the first tile in a corner of the area to be covered, placing the sides of the grid with the female joints towards the area where you want to lay the floor.

2



Click the male joints of the second tile into the female joints.

3



Lay the tiles of the second row and make sure that the male joints click into the female joints of the first row.

4



Click the tiles of the second row (except for the first tile) into the tiles of the first row and into the tiles already laid in the second row.

5



Make sure that the two sides of the files you have laid have female joints and that in the two corresponding sides of the tile to be clicked in you have male joints.

6



Example shows correctly installed floor.