



**HORTUS**<sup>®</sup>  
outdoor wood flooring

## DECKING PUZZLE 1200

(finished product with grid base): 1200 x 95 x 22 mm

### RUNNER pattern

Hortus Decking  
Puzzle 1200  
RUNNER pattern

Surface covered:  
1 m<sup>2</sup> approx.



## INSTALLATION

(runner pattern)



**1** Place the grids in vertical rows with the following distances: 1° row at 1 cm from the beginning of the flooring (that is, 1 cm from the head of the plank that will be installed), the 2° row at 44 cm from the 1° row (that is, leaving an empty space of 44 cm), the 3° row at 2 cm from the 2° row, the 4° row at 44 cm from the 3° row, the 5° row at 2 cm from the 4° row, etc.



**2** Put the first plank inserting the upper fins of the grids of the first row, in the longitudinal groove on the side of the plank. To do this, tilt the plank on the long side and push it towards the upper fins. Once inserted the upper fins in the groove, lay the other side of the plank on the lower fins of the first row of grids.



**3** Firmly push down the side of the plank not yet fixed on the fins of the grids until you hear a click.



**4** After having laid down all the planks of the first row, cut, in half the first plank of the second row and place the piece of plank making sure that the head with the female dap joint ends in the side in which it is foreseen the installation of the flooring.



**5** Before to fix the piece of cut plank in the grids, it is necessary to insert the tapped head of the plank in the dap joint female of the head of the previous plank.



**6** Verify that the dap joint (male-female) of the 2 planks that are being installed, ends exactly in the middle of the two rows of grids 2 cm far off each other.



**7** After having combined the heads of the 2 planks and having fixed the groove on the long side of the same planks in the upper fins involved in the assembly, place the other long side of the planks on the lower fins of the grids below.



**8** Press firmly down on the long side of the 2 planks not yet fixed in the fins of the grids until you hear a click. Make sure you have not to hook the final part of the right plank in the grid below so as to enable the insertion of the male dap joint in the next plank.



**9** Repeat the above steps with all the planks making sure that the ends of the planks are in line on alternate rows.



**10** Example shows correctly installed floor.

N.B. Near to the borders of the flooring glue or screw the heads of the staves with the grids below in order to avoid the sliding of the staves outwards.